

How to apply **PENSTICK®** on glass

PENSTICK® is a cling film that adheres without adhesives on smooth, glossy surfaces such as window glass. **PENSTICK®** can be removed easily without any residues even after a long time. For easy application we recommend the following procedure:

- Make sure that the surface of the substrate (for example the window) is clean.
- Spray the window area with a mixture of water and soap. Spray bottles as they are used for commercial window cleaner are suitable for this purpose. Alternatively you could also use a sponge to wet the surface.
- Remove the film from the liner and arrange one side of the film onto the glass. Smooth down gently the edges with your hand.
- Smooth down water and air bubbles between film and glass over the narrow side. The best results you'll get with a wallpapering role. If you want to correct the position of the film remove it and start once again. If the glass is still wet enough you could also easily replace it without removing.
- If the cling film gets dusty or dirty you can clean it with water and soap.